

[n ó t o s]

COLLECTION ACCESSORIES



Wooden couvert tray 25

O30149 [6]
25.0 x 25.0 H6.0 cm
10" x 10" H2.5"
[95416]



Wooden tray 35

O30148 [6]
35.0 x 9.0 H6.0 cm
13.75" x 3.5" H2.5"
[95413]



Low wooden tray 35

O30147 [6]
35.0 x 9.0 H4.0 cm
13.75" x 3.5" H1.5"
[95412]



Wooden tray 25

O30146 [6]
25.0 x 9.0 H6.0 cm
10" x 3.5" H2.5"
[95415]



Low wooden tray 25

O30145 [6]
25.0 x 9.0 H4.0 cm
10" x 3.5" H1.5"
[95414]



Y metallic riser

O30144 [6]
30.4 x 10.4 H13.2 cm
12" x 4" H5.25"
[95410]



Square metallic riser

O30143 [6]
15.1 x 15.1 H15.3 cm
6" x 6" H6"
[95409]



Wooden plate 14

O30156 [6]
D14.0 H0.3 cm
D5.5" H0.25"
[95411]



Cork plate 14

O30150 [12]
D14.0 H0.3 cm
D5.5" H0.25"
[95417]



Cork placemat 33

O30151 [12]
D33.0 H0.7 cm
D13" H0.5"
[95418]



Cork oval inlay 25

O30155 [12]
23.7 x 7.3 H0.6 cm
9.5" x 3" H0.5"
[95422]



Cork oval inlay 18

O30154 [12]
16.7 x 7.3 H0.6 cm
6.5" x 3" H0.5"
[95421]



Cork outer shell for bowl 14

O30153 [12]
D15.3 H4.5 cm
D6" H1.75"
[95420]



Cork outer shell for bowl 9

O30152 [12]
D9.3 H5.7 cm
D3.75" H2.25"
[95419]

