



Plate
6334P467 D 11"
 (Plate Cover 5379S792)
6334P466 D 10 1/4"
 (Plate Cover 5379S791)
6334P465 D 9 1/2"
6334P464 D 7 3/4"
6334P461 D 6 1/4"



Pasta/Presentation Bowl
6334P488 D 11" H 2 1/8" (22 oz)
 (Plate Cover 5379S792)



Rimmed Soup/Pasta Bowl
6334P469
 D 9 1/4" H 1 3/4" (10 1/2 oz)



Grapefruit Bowl
6306P796
 D 6 1/4" H 1 7/8" (7 1/2 oz)
 Fruit Dish
6306P794
 D 5 1/8" H 1 1/2" (4 oz)



Stack Bouillon
6306P797
 D 3 1/4" H 2 3/4" (7 oz)
 Saucer
6334P475 D 5 1/2"



Stack Bouillon Cup
6306P763
 D 4" H 2 1/2" (11 1/4 oz)
 Saucer
6334P475 D 5 1/2"



Stack Coffee Mug
6334P491
 L 4 1/8" H 3 1/4" (10 oz)



Stack Coffee Cup
6334P492
 L 4 3/8" H 2 3/4" (8 oz)
 Saucer
6334P475 D 5 1/2"



Stack Coffee Cup
6334P474
 L 4 1/8" H 2 1/2" (6 3/4 oz)
 Saucer
6334P475 D 5 1/2"



Creamer w/Handle
6334P489
 L 3 3/4" H 2 5/8" (5 oz)



Sugar Packet Holder
6334P490
 L 3 7/8" H 1 7/8" (6 oz)



Sauce Dish
6334P471
 D 3 1/8" H 1" (1 3/4 oz)



Oval Rim Platter
6302P250
 L 15 1/2" W 10 7/8"



3 Compartment Stacking Tray
6302P279 L 15 7/8" W 6 5/8"
 Plate Cover
5371S500 L 15 7/8" W 6 5/8"



Square Tray
6302P271*
 L W 9 1/2"



Rectangle Tray
6302P272
 L 7 1/4" W 5 1/2"

accessories



Rectangular Sorbet Dish w/ 3 Wells
6302P267 L 12 1/8" W 5" H 1 1/8"
 (2 oz Each Well)



Dish
6302P261 D 4"




Square Bowl
6302P270*
 L W 5 1/8" (4 oz)



Tumbler
6302P262 D 2 1/4" H 2" (3 oz)
6302P263 D 2 1/4" H 1 3/8" (1 3/4 oz)
 Underliner Dish
6302P261 D 4"



Pourer
6302P264 L 3 1/4" H 2 1/4" (3 oz)
 Underliner Dish
6302P261 D 4"



Butter/Oil Dish w/Lid
6302P265
 D 3" H 1 7/8"
 (1 1/2 oz)

*Non-Stock

D=Diameter L=Length W=Width H=Height • All Products are Measured at Max Capacity (oz) For further details contact your customer service rep.