


Venice Pasta Bowl **A100P456** D 12 5/8" H 3 1/2" (2 1/4 qt)



Coupe Bowl **A100P358** D 9" H 3 1/4" (67 oz) **A100P169** D 7 1/2" H 2 5/8" (30 1/2 oz)



Cucina Pasta Bowl **A100P213** D 9 1/2" H 3 3/8" (64 1/2 oz)



Canton Bowl **A100P365** D 8" H 3" (54 oz) **A100P366** D 7 1/2" H 2 3/4" (42 oz)



Baja Bowl **A100P158** D 9 1/8" H 2 1/2" (45 oz)



Rolled Edge Pasta Bowl **A100P050** D 11 3/4" H 2 1/4" (26 oz)



Lions Head Bowl **A100P431** L 5 7/8" W 4 7/8" H 3 1/2" (16 oz)



(13 1/2 oz)

Nappy Bowl **A100P032** W 5" H 2 3/8"



Astro Bowl **A100P170*** (18 oz w/12 oz Fill Line) **A100P171** D 4 7/8" H 2 1/4" (12 oz w/8 oz Fill Line)



Grapefruit Bowl **A100P432** D 6 5/8" H 1 3/4" (8 oz) **A100P435** D 6 1/2" H 1 3/4" (10 oz)



Rolled Edge Fruit Dish **A100P031** D 5 3/4" H 1 1/2" (7 1/2 oz) **A100P030** D 4 1/2" H 1 3/8" (3 1/2 oz)



Oval Dish **A100P143** L 5 1/8" W 4" H 1 1/4" (3 1/2 oz) (Clear glaze)



Bouillon Cup **A100P079** D 4" H 2 1/2" (9 oz) Saucer **A100P018** D 6"



Bouillon Cup A100P085 D 4 1/4" H 2 1/2" (8 1/2 oz) Saucer A100P018 D 6"



Onion Soup Crock **A100P015** L 5 1/4" W 4 5/8" H 2 3/8" (10 oz) (Clear glaze)



Oval Rarebit (Clear glaze)
A100P151 L 11 3/4" W 5 3/4" (15 oz)
A100P152 L 10" W 5" (12 oz)
A100P153 L 8 3/4" W 4 1/8" (8 oz)
A100P154 L 7 7/8" W 3 3/8" (4 1/2 oz)



Oval Baker **A400P157** L 5 3/4" W 4" H 1 7/8" (8 oz) (Polar white)



Fry Pan Server A100P001 L 8 1/4" W 7 3/4" H 1 3/8" (18 oz) Handle 3" (Clear glaze)



Shirred Egg Dish **A100P002** L 9 1/4" W 7 7/8" H 1 7/8" (23 oz) (Clear glaze)



Handled Casserole/Soup A100P010 D 5 3/4" H 1 7/8" (11 oz) Handle 1 5/8" (Clear glaze)



Souffle Dish A400P605 D 4" H 2" (8 oz) (Polar white)



Celery Tray **A100P004** L 10 1/8" W 4 5/8" H 1 1/8" **A100P003** L 7 1/2" W 3 5/8" H 1 1/8"



Divided Condiment Dish **A400P075** L 7 1/2" W 2 1/4" (1 oz Each Well) (Polar white)



Fluted Ramekin A100P604 D 3 7/

A100P604 D 3 7/8" H 1 7/8" (6 oz) (Clear glaze) A100P600 D 3 1/2" H 1 5/8" (4 oz) (Clear glaze) A100P603 D 3 1/2" H 1 1/2" (2 3/4 oz) (Clear glaze) A100P601 D 2 7/8" H 1 3/8" (2 oz) (Clear glaze) A400P604 D 3 7/8" H 1 7/8" (6 oz) (Polar white) A400P601 D 2 7/8" H 1 3/8" (2 oz) (Polar white)



Salsa Dish **A100P086** D 3 1/8" H 1 5/8" (3 oz)



Ramekin **A100P302** D 2 7/8" H 1 1/2" (2 1/2 oz)



Flat Sided Teapot w/Lid A100P005 (12 oz) (Clear glaze) Replacement Lid A100P012 (Clear glaze)



Allegheny Creamer A100P082 L 3 1/2" H 3" (3 1/2 oz) (Clear glaze)



Astro Creamer A100P080 L 2 3/8" W 2 1/4" (2 3/8 oz)



Sugar Packet Holder **A100P389** L 3 1/2" H 2 3/4" (6 oz) (Clear glaze)



Low Cup **A100P054** L 5" H 2 7/8" (9 oz) Saucer **A100P018** D 6"



AD Cup **A100P410** L 3 3/8" H 2 1/2" (3 oz) AD Saucer **A100P411** D 5"



Acapulco Mug **A100P049** L 4 3/4" H 3 1/2" (10 oz)



Conical Mug A100P038 L 4 7/8" H 4 5/8" (12 oz)



Mug **A100P046** L 4 3/4" H 3 1/2" (10 oz)



Coffee Mug A100P070 L 4 5/8" H 4 1/2" (9 oz)

