



Plate
 6900E500 D 12"
 6900E501 D 11"
 6900E502 D 10 5/8"
 6900E503 D 10"
 6900E504 D 9"
 6900E505 D 8"
 6900E506 D 6 1/2"



Platter
 6900E518 L 15 1/2" W 10 3/4"
 6900E519 L 13 1/4" W 9"
 6900E520 L 11 1/2" W 7 3/4"
 6900E521 L 10" W 6 3/4"
 6900E522 L 8 1/4" W 5 7/8"
 6900E430 L 7" W 4 1/2"



Pasta Bowl
 6900E514 D 12" H 1 5/8" (13 oz)
 Rim Soup Bowl
 6900E513 D 9" H 1 1/2" (10 oz)



Presentation Bowl
 6900E557 D 11 1/2" H 2 3/8" (18 oz)



Grapefruit Bowl
 6900E516 D 6 1/4" H 1 7/8" (9 1/2 oz)
 Fruit Dish
 6900E515 D 5 1/8" H 1 1/2" (5 1/4 oz)



Stack Soup
 6900E556 D 4 3/4" H 2 1/4" (12 oz)
 6900E512 D 4 1/4" H 2 1/8" (10 oz)
 Saucer Double Well
 6900E530 D 6 1/4"



Stack Bouillon
 6900E511 D 3 1/4" H 2 3/4" (7 oz)
 Saucer Double Well
 6900E530 D 6 1/4"



Stack Cappuccino Cup
 6900E529 W 4 1/2" H 3" (11 1/4 oz)
 Saucer Double Well
 6900E530 D 6 1/4"



Stack Coffee Cup
 6900E507 W 4 1/4" H 2 3/4" (7 oz)
 Saucer Double Well
 6900E530 D 6 1/4"



Stack AD Cup
 6900E531 W 2 1/8" H 3 1/4" (2 3/4 oz)
 Saucer
 6900E532 D 4 3/4"



Stack Mug
 6900E510 W 4 3/8" H 3 5/8" (10 oz)