



A.D. Cup (Stackable)
R422 535 (2 3/4" / 7 cm), 3 doz.
3 1/2 oz. / 10.4 cl



Mug (Stackable)
R422 560 (3 3/8" / 8.5 cm), 3 doz.
9 oz. / 26.6 cl



Sauce Boat
R422 825 (3" / 7.6 cm), 3 doz.
7 oz. / 20.7 cl



A.D. Saucer (Fits 535)
R422 505 (4 3/4" / 12 cm), 3 doz.



Shaker Salt
R422 910 (2" / 5.1 cm), 3 doz.
Shaker Pepper
R422 911 (2" / 5.1 cm), 3 doz.



Sugar Packet Holder
R422 905 (3 1/2" / 8.8 cm), 3 doz.



Cup Alta
R422 510 (3 1/2" / 8.9 cm), 3 doz.
7 oz. / 20.7 cl



Teapot (w/ Lid)
R422 861 (3 7/8" / 9.8 cm), 2 doz.
11 oz. / 32.5 cl



Cup (Stackable)
R422 530 (3 3/8" / 8.5 cm), 3 doz.
7 oz. / 20.7 cl



Ramekin
R422 610 (3 1/4" / 8.1 cm), 6 doz.
1 1/2 oz. / 4.4 cl

Lid Only (fits 861)
†R422 861L (2 1/2" / 6.3 cm), 6 doz.



Cup (Stackable)
R422 536 (3 1/8" / 7.9 cm), 3 doz.
9 oz. / 26.6 cl



Creamers
R422 802 (2 1/2" / 6.4 cm), 3 doz.
4 oz. / 11.8 cl
R422 807 (3" / 7.6 cm), 3 doz.
6 1/2 oz. / 19.2 cl



Saucer (Fits 510, 530 & 536)
R422 500 (5 3/4" / 14.5 cm), 3 doz.