




Square Plate
 6900E537 L W 12"
 6900E538 L W 10"
 6900E539 L W 8"
 6900E540 L W 6 1/2"
 6900E541 L W 5 1/2"
 6900E570 L W 3 1/2"



Square Tray
 6900E534 L W 11 1/2"
 6900E524 L W 10 1/2"
 6900E535 L W 8 1/2"
 6900E536 L W 6 3/4"



Square Rim Plate
 6900E599 L W 12"



Rectangle Tray
 6900E553 L 14" W 7"
 6900E523 L 11" W 6"
 6900E554 L 9 1/2" W 5"
 6900E555 L 7" W 4 3/8"



Rectangle Plate
 6900E559 L 15" W 7"
 6900E563 L 11" W 7"
 6900E558 L 9 1/2" W 5"



Handled Rectangle Tray
 6900E404 L 13" W 6 1/2"
 6900E405 L 11 3/4" W 5 3/4"
 6900E406 L 10" W 4 7/8"
 6900E407 L 8" W 3 7/8"



Handled Square Tray
 6900E424 L W 6"



Square Bowl
 6900E578 L W 6 3/8" H 3" (34 oz)
 6900E542 L W 5 1/4" H 2 1/4" (18 oz)
 6900E543 L W 4" H 1 3/4" (6 oz)



Square Bowl
 6900E590
 L W 3 1/8" H 1 1/4" (3 1/4 oz)



Square Tray
 6900E411 L W 5 7/8" H 1"
 6900E412 L W 5" H 5/8"
 6900E413 L W 3 3/8" H 3/4"



Rectangle Bowl
 6900E414 L 5 7/8" W 4 1/4" H 1 7/8" (11 3/4 oz)
 6900E415 L 5 7/8" W 4 1/4" H 1 1/2" (10 oz)
 Rectangle Dish
 6900E416 L 5 7/8" W 4 1/4" H 7/8"



Rectangle Tray
 6900E596
 L 3 1/4" W 2 3/8" (2 oz)



Deep Rectangle Tray
 6900E423
 L 7 5/8" W 5 3/4" H 1 5/8"



Rectangle Deep Tray
 6900E580
 L 6 7/8" W 5 1/8" H 1 1/4"



Rectangle Tray
 6900E569
 L 7 3/4" W 4 1/8" H 1" (10 1/2 oz)



Square Bowl
 6900E418 L W 5 7/8" H 1 7/8" (22 3/4 oz)
 6900E419 L W 5 1/4" H 1 1/2" (20 3/4 oz)
 Square Dish
 6900E420 L W 5 1/2" H 1"



Square Bowl
 6900E560
 L W 4 7/8" H 2 3/8" (12 oz)



Square Bowl
 6900E571
 L W 3 5/8" H 2" (6 oz)



Square Bowl
 6900E417
 L W 4" H 1 5/8" (6 1/4 oz)