



**10" Multi-Chef™ Bronze Warmer Kit with Track Grill**

21.6 x 13.6 x 10 in  
58.9 x 34.4 x 25.4 cm

**Item # SK052**

Fuel not included



**7" Multi-Chef™ Bronze Warmer**

21.6 x 13.6 x 7 in  
54.9 x 34.5 x 17.9 cm

**Item # SM308**



**10" Multi-Chef™ Bronze Warmer**

21.6 x 13.6 x 10 in  
58.9 x 34.4 x 25.4 cm

**Item # SM307**



**7" Multi-Chef™ Bronze Cooler with Ice Tub**

25.3 x 14.3 x 8.5 in  
64.3 x 36.3 x 21.6 cm

**Item # SM318**



**3 Tier Bronze Bakery Case with Clear Acrylic Cases**

15.3 x 23.3 x 15.5 in  
38.9 x 59.2 x 39.4 cm

**Item # BK017**



**2-Tier Acrylic Bakery Case with Bronze Metal Stand**

22.4 x 15 x 13 in  
56.9 x 38.1 x 33 cm

**Item # BK022**



**3-Tier Acrylic Bakery Case with Bronze Metal Stand**

22.4 x 15 x 17.2 in  
58.9 x 34.4 x 43.7 cm

**Item # BK023**

