



**Coupe Plate**  
 11070565 D 11 3/4"  
 11070544 D 11"  
 11070566 D 10"  
 11070543 D 9"  
 11070567 D 8"  
 11070568 D 6"



**Spice Plate**  
 11070579 L 12" W 10 1/4"  
 11070580 L 10" W 9"  
 11070581 L 8" W 7"  
 11070582 L 6" W 5 1/8"



**Zest Platter**  
 11070585 L 12" W 10 1/4" H 2 1/8"  
 11070586 L 10" W 9 1/2" H 2"  
 11070587 L 8" W 7 3/4" H 1 3/4"



**Oval Platter**  
 11070605 L 14 1/4" W 10 1/4"



**Oval Relish Platter**  
 11070572 L 12"  
 11070573 L 9"



**Square Plate**  
 11010407 L W 11 1/4"  
 11010408 L W 9"  
 11010409 L W 7"



**Square Plate**  
 11070553 L W 10 1/2"  
 11070619 L W 7 1/2"  
 11070620 L W 6 1/2"  
 11070621 L W 4"



**Rectangle Tray**  
 11070551 L 13 1/2" W 10 5/8"



**Rectangle Tray**  
 11070552 L 14 1/2" W 6 1/2"  
 11070556 L 12 1/2" W 7 1/2"  
 11070549 L 11 3/8" W 5 1/2"  
 11070550 L 10 5/8" W 6 1/2"  
 11070618 L 8" W 4"



**Serving Stand**  
 5379S799  
 L 10 1/2" W 7" H 14 1/2"  
 (For 11070550)



**Coupe Bowl**  
 11070545 D 11 1/2" (65 oz)  
 11070569 D 10" (38 oz)  
 11070570 D 8 1/2" (27 oz)  
 11070571 D 5" (4 oz)



**Square Bowl**  
 11010414 L W 10 1/4" (10 oz)  
 11010415 L W 9" (8 1/4 oz)  
 11010416 L W 7 3/4" (7 1/2 oz)



**Taster Tray**  
 11070577 L 10" W 5"



**Stack Tray**  
 11070559 D 8" (44 oz)  
 11070560 D 6 1/2" (21 oz)  
 11070561 D 5 1/2" (10 1/2 oz)  
 11010470 D 4" (4 oz)  
 11010471 D 3" (2 oz)



**Tulip Bowl**  
 11070542 D 8 3/4" H 4 1/4" (67 oz)  
 11070541 D 7" H 3 1/4" (36 1/2 oz)  
 11070540 D 5 1/2" H 2 3/4" (18 3/4 oz)  
 11070539 D 4" H 2" (6 3/4 oz)  
 11070538 D 2 3/4" H 1 1/4" (2 1/4 oz)



**Casual Square Bowl**  
 11070601 L 10" (68 oz)  
 11070602 L 8" (32 oz)  
 11070603 L 6" (12 oz)  
 11070604 L 4" (4 oz)



**Essence Bowl**  
 11070596 D 8" (30 oz)  
 11070597 D 6 1/2" (19 1/4 oz)  
 11070598 D 5 1/2" (11 1/2 oz)  
 11070595 D 4 1/2" (5 oz)