



NE-3280 FULL 1/1 GASTRONORM MICROWAVE

This robust oven handles the most rigorous of duties. With power of up to 3200W plus the large capacity, it can sustain consistently fast output - making it the ideal choice for cooking multiple dishes simultaneously. Capable of taking two 1:1, 10cm Gastronorm dishes, or with the shelf removed one 1:1, 20cm Gastronorm dish.



Microwave
3200W



NE-3280 TOUCH

- 4 power levels
- Quad Emission. 4 magnetrons and rotating wave guides for fast and even heating
- Positive action dial control timer
- Stainless steel body and cavity
- Removable shelf
- Pull-to-open drop down door
- Cycle counter – records number of operations
- Programmable touch controls
- 16 programs to include 2 and 3 stage heating
- Program lock allows one touch operation
- Manual heating with repeat function
- Accommodate Gastronorm 1/1 (530 x 325mm) containers in 2 layers

NE-1880 Touch Specifications		
Power Source		50Hz, single phase 230-240 V
Required Power		22.3A 5220 W
Frequency		2450 MHz
Outer Dimensions		650x526x471mm
Oven Dimensions		535x330x250mm
Output*	High	3200 W
	Medium	1600 W
	Low	340 W
	Defrost	170 W
	Stand	0 W
Timer	High	15 min
	Medium	15 min
	Low	60 min
	Defrost	60 min
	Stand	60 min
Programs		16
Memory		3 stage
Net Weight		65 kg
Cubic Capacity		44 litres (1.56 cu. ft)
*IEC 705 - 88 Test Procedure Specifications subject to change without notice		

PROGRAM LOCK

To allow one touch operation, especially for applications such as sites where a variety of regular programs are used, fast food sites and where de-skilling has been implemented.

PROGRAMMABLE MEMORY PADS

The power level and heating time for regular dishes can be programmed into the 16 memory pads for speed of operation and consistent results.

PLACEMENT OF YOUR OVEN

- Oven must be placed on a flat, stable surface. For proper operation, the oven must have sufficient air flow.
- A gap of at least 5cm (2") must be available at the right and left hand sides and back wall of the oven.
- A minimum space of 20cm (8") must be left above the oven and the 2 exhaust vents at the rear.
- Do not place the oven on a shelf directly above or beside a gas or electric hob or cooker. This may cause damage to the oven.
- It is dangerous to position this oven on a shelf which is so high that food and accessories cannot be safely removed by the user.
- Do NOT attempt to stack these ovens.

2 & 3 STAGE HEATING

Allows the power level to change during heating e.g. 'Defrost' for 3 minutes, then 'High' for 1 minute in a single operation thus freeing the operator from constant attendance to reset controls.

POWER SUPPLY

NE-3280 30 amp, hardwired



For further information,
Email: commercialovens@eu.panasonic.com
Visit: www.panasonic.co.uk/professionalkitchen