



flat plate wide rim

- 571816 6.6" (36) ♥
- 571820 8.0" (36) ♥
- 571825 9.7" (12) ♥
- 571828 10.9" (12) ♥
- 571830 12.0" (12) ♥



flat plate steep rim

- 570019 7.7" (36) ♥
- 570024 9.7" (24) ♥
- 570027 10.8" (12) ♥



half-deep plate

- 570120 8.2" 8.8 oz (24)
- 570123 9.2" 11.2 oz (24) ♥



oval platter

- 572028 11.0" x 7.3" (12) ♥
- 572032 12.4" x 8.3" (12)
- 572036 14.2" x 9.5" (12) ♥



fruit bowl

- 573064 5.4" 6.1 oz (36) ♥



salad bowl

- 573166 6.3" 12.5 oz (36) ♥
- 573171 8.4" 32.1 oz (12) ♥



cream soup cup stackable

- 572926 4.0" 9.5 oz (36) ♥
- use saucer 576918



demitasse cup

- 575159 2.7" 3.0 oz (36)
- use saucer 576909



cup

- 575168 3.5" 6.8 oz (36) ♥
- use saucer 576920



tall demitasse cup

- 575259 2.7" 3.4 oz (36) ♥
- use saucer 576909



tall cup

- 575375 3.3" 8.8 oz (36) ♥
- use saucer 576918



cup stackable

- 575118 3.2" 6.1 oz (36) ♥
- use saucer 576918



hot chocolate cup

- 575318 3.0" 6.1 oz (36)
- use saucer 576918



demitasse saucer

- 576909 4.5" (36) ♥



saucer

- 576920 5.7" (36) ♥
- 576918 6.1" (36) ♥