



Banquet Rim Plate
6382P872 D 11 1/4" (7" Well)
(Plate Cover 5379S784)
6382P873 D 10 1/4"
6382P874 D 9 1/2"
6382P875 D 8 1/4"
6382P876 D 6 1/4"



Wide Rim Plate
6382P870 D 11 1/4" (5 1/2" Well)
(Plate Cover 5379S784)



Mid Rim Plate
6382P871 D 11 1/4" (6 1/4" Well)
(Plate Cover 5379S784)



Rim Pasta Plate
6382P877 D 11 1/4" H 2 1/4" (30 oz)
(Plate Cover 5379S784)



Deep Presentation Bowl
6382P880
D 11 1/4" H 2 1/8" (6 1/4" Well)
(Plate Cover 5379S784)



Deep Presentation Bowl
6382P881
D 9 1/2" H 2" (4 3/4" Well)



Rim Soup Plate
6382P878
D 9" H 2" (14 oz)



Rim Fruit
6382P879
D 5 1/2" H 2 1/4" (11 1/2 oz)



Bowl
6382P882 D 5 1/2" H 2 1/8" (16 oz)
6382P883 D 4 3/4" H 1 5/8" (10 oz)
6382P884 D 4" H 1 1/4" (5 1/2 oz)
Universal Saucer
6382P889 D 6 1/4" (Fits P883, P882)



Bouillon Cup
6382P886 D 4 1/4" H 2 1/2" (9 3/4 oz)
Universal Saucer
6382P889 D 6 1/4"



Breakfast Cup
6382P885 L 5 1/8" H 2 1/2" (9 3/4 oz)
Universal Saucer
6382P889 D 6 1/4"



Cup
6382P887 Coffee L 4 3/8" H 3 1/4" (8 oz)
6382P890 Espresso L 3 1/2" H 2 1/2" (4 oz)
Saucer
6382P889 Universal D 6 1/4" (Fits P887)
6382P891 D 5" (Fits P890)



Stack Mug
6382P888 L 4 3/8" H 4" (10 1/2 oz)
Universal Saucer
6382P889 D 6 1/4"